

# Public Address Series

## Wall Speaker User Manual

### Product Picture




Front




Rear

### Transformer Connection Diagram




### Installation Diagram



- ① Dig a hole that make it bigger than bottom box, then install the box, the distance is (116mm) to orientation hole, then hang the speaker on the orientation hole after fixup the screw.
- ② Dig a hole that make it bigger than bottom box, then install the box, the distance is (36mm) to orientation hole, then hang the speaker on the orientation hole after fixup the screw.
- ③ According to speaker backboard orientation hole, fixup the screws on the wall hole position, then hang the speaker.

### Diagram for back cover orientation hole dimension



### Specifications

Model	TF-700
Power Taps@100V	0.75W, 1.5W, 3W, 6W
Power Taps@70V	0.37W, 0.75W, 1.5W, 3W
Impedance	COM/13.3K $\Omega$ /6.7K $\Omega$ /3.3K $\Omega$ /1.7K $\Omega$
SPL(1W/1M)	91dB $\pm$ 3dB
Freq Response	100-16KHz
Dimensions	245X212X95mm
Weight	1.9Kg

