




T-5/T-15/T-25/T-35/T-45 T-5F/T-15F/T-25F/T-35F/T-45F
T-7/T-17/T-27/T-37/T-47 T-7F/T-17F/T-27F/T-37F/T-47F
T-9/T-19/T-29/T-39/T-49 T-9F/T-19F/T-29F/T-39F/T-49F
(With separated torroidal transformer)



T-5/T-15/T-25/T-35/T-45
T-5F/T-15F/T-25F/T-35F/T-45F



T-7/T-17/T-27/T-37/T-47
T-7F/T-17F/T-27F/T-37F/T-47F



T-9/T-19/T-29/T-39/T-49
T-9F/T-19F/T-29F/T-39F/T-49F



Plastic box



Metal box

Specifications

Model	T-5/T-7/T-9	T-15/T-17/T-19	T-25/T-27/T-29	T-35/T-37/T-39	T-45/T-47/T-49
Rated Power	6W	30W	60W	120W	200W
Type	Resist	Trans	Trans	Trans	Trans
Steps	5	5	5	5	5
Parts	3.5 × 2.0 Screw				

Model	T-5F/T-7F/T-9F	T-15F/T-17F/T-19F	T-25F/T-27F/T-29F	T-35F/T-37F/T-39F	T-45F/T-47F/T-49F
Rated Power	6W	30W	60W	120W	200W
Type	Resist	Trans	Trans	Trans	Trans
Steps	5	5	5	5	5
Parts	3.5 × 2.0 Screw				

Attn: "F" means 24v input

1. T-5/T-5F, T-7/T-7F, T-9/T-9F can use standard common plastic bottom box (L86× W86× H50mm) for installation, for other models, if do not use special metal box when installation, you has to fix the transformer in other position, and coonect the down-lead to the volume control switch.

2. You have to use our special metal box (L82.5 × W82.5 × H80mm) if use special metal box when installation. Special bottom box you have to buy by yourself.